

---

# Installing the network card - Acorn Risc PC


---

## Installation

The section Adding a network card in the Welcome Guide chapter Internal expansion tells you how to fit the network card.

## Installing the network

See Connecting up an Acorn Access network (on the printed A4 card supplied with the network card) for information on installing an Access network. The T-piece supplied is slightly different from those illustrated in the instructions, but is used the same way.



It is strongly recommended that any Acorn Access network consisting of more than six computers or extending to more than one room is separately earthed at one point.

Make sure that network cable is always kept away from mains wiring.

**For the correct method of earthing, consult your dealer.**

Copyright © 1994 Acorn Computers Limited

Published by Acorn Computers Limited

Part number 0484,491

Issue 1, March 1994