

B2P HiWORDWISE PLUS

This disk contains the B2P Second Processor, 'Hi' version of Computer Concepts' Word Processor, WORDWISE PLUS. The 'Hi' version functions EXACTLY as the normal version except for the following two differences.

- 1: 42K of text may be edited.
- 2: Preview is always in 80 column.

To use HiWORDWISE you MUST have a PMS B2P Second Processor connected to your BBC, AND the normal WORDWISE PLUS ROM MUST be present in the BBC. If either of these conditions are not fulfilled then the message 'I will not run this code' is generated and BREAK has to be pressed to regain control.

To enter HiWORDWISE, proceed as follows:

- 1: Ensure that your WORDWISE PLUS ROM is in the BBC:
- 2: Connect the B2P as described in the User Guide.
- 3: Type *B2PON to activate the Second Processor.
- 4: Insert the HiWORDWISE disk in drive 0.
- 5: Type *HIWW <RETURN>

NOTES: Pressing BREAK' alone will leave you in HiWORDWISE PLUS with text intact but pressing CTRL-BREAK will re-enter the default' language, with the result that WORDWISE text may be lost.

COPYRIGHT NOTICE: WORDWISE PLUS is copyright Computer Concepts, and any copying of the HiWORDWISE disk supplied is breach of copyright, and any individual, school, college, or other organisation found in breach of copyright will be prosecuted.