

IMPORTANT NEW INFORMATION

StrongARM CARDS NOW EX-STOCK!!

New Product Announcement:

Casio QV-10 Digital Camera

We now have available, the Casio QV-10 Digital Camera for you to sell alongside the Acorn Computer Range: This will open up a new section of end-users and businesses which we believe will put more Acorn products into homes and businesses:

Just think how many people would benefit from the use of a digital camera:

- Estate Agents
- Insurance/Loss Adjusters
- Journalists/Researchers
- Students and
- anyone wanting to enhance reports, tenders or help in selling items.

So when you are selling an Acorn computer, mention the Casio camera, judge the reaction, and go for the sale. We are sure you will come across very few objections:

Please find enclosed a copy of the casio camera details, including all specifications with this pack.

We will be offering the Casio camera complete with all software and relevant cables under the following product codes and prices:-

ART Product Code	Description	RRP Price	Dealer Price
CAS10	Casio QV-10 Camera	£349.00 +VAT	£296.65 +VAT
ADK65	Casio Mains Adaptor	£12.75 +VAT	£10.84 +VAT

Printer Compatibility:

Please find enclosed a list of all printers that are supported by Acorn's printer drivers version 1.53 (This is available to download from the Dealer Web Site *Free of Charge*)

Printer Compatibility for Version 1.53

12th May 1997

Acorn JP-150	ABC 24 pin Colour Overture 106 (Epson FX 80) Overture 110+ (Epson FX 80) Overture 112 (HP Laserjet II) Prolaser 12 (HP Laserjet II) Proscript 12 (Generic PostScript) Projet Projet 11 PN48 Note Book Printer II	EPL 8100 (HP Laserjet III) Stylus 400 (Epson Stylus 800) Stylus 400 + (Epson Stylus 800) Stylus 500 (Stylus Colour II) Stylus 800 Stylus 800 + (Epson Stylus 800) Stylus 820 Stylus 210 Stylus 300 (Epson Stylus 800) Stylus 1000 (Epson Stylus 800) Stylus Colour Stylus Colour II Stylus Colour IIs (Only up to 360 x 360 DPI) Stylus Pro Stylus Pro XL
Apple Imagewriter II LaserWriter LaserWriter+ LaserWriter II-NT LaserWriter II-NTX LaserWriter !6/600 (Generic PostScript) LaserWriter Select 360 (Generic PostScript) Personal LaserWriter (Generic PostScript)	Compaq Pagemarq 15 (Generic PostScript) Pagemarq 20 (Generic PostScript)	Facit P8086 (HP Laserjet III)
Brother HJ1001 Ink Jet (Canon Bubblejet, Epson LQ 860) M1818 (Epson FX 85) HL-10 (HP Laserjet III) HL-10 PS (Generic PostScript) BL-6V (HP Laserjet III) HL-10V (HP Laserjet III) HJ 1260 (Generic PostScript) HJ 631 (HP Laserjet II) HJ 660 (HP Laserjet IV) HL 630 (HP Laserjet II)	Dataproducts LZR 888 (HP Laserjet IV) T8 (HP Laserjet III)	Fujitsu DX 2250 (Epson FX 80) DX 2300 (Epson FX 80) DL 900 (Epson LQ 860) DL 1100 (Epson LQ 860) DL 1150 (Epson LQ 860) DL 1200 (Epson LQ 860) DL 1250 (Epson LQ 860) DL 3600 (Epson LQ 860) DL 4600 (Epson LQ 860) DL 5600 (Epson LQ 860) DL 5800 (Epson LQ 860) B 100 (HP Deskjet +) B200 (HP Deskjet +) VM600 (HP Laserjet III) VM600E (HP Laserjet III) VM800 (HP Laserjet III) VM2200 (HP Laserjet III)
Calcomp Colormaster Plus XF (Generic PostScript) Colormaster Plus XFA3 (Generic PostScript)	ENCAD Novajet III	General Parametrics Corporation Spectra Star GLX (Generic PostScript) Spectra Star GTX (Generic PostScript)
Canon BJ-10e (Canon BJ-10) BJ-10ex (Canon BJ-10) BJ-10sx (Canon BJ-10) BJ-10sxw (Canon BJ-10) BJ-30 BJ-130e BJ-200 BJ-200ex BJ-220 (Canon BJ-220) BJ-230 (Canon BJ-230) BJ-300 (Canon BJ-300) BJ-330 (Canon BJ-330) BJC-70 BJC-210 BJC-600 BJC-600e BJC-610 BJC-800 BJC-4000 BJC-4100 LBP-4+ (LQ 860 ensure it is in Epson Emul. mode) LBP-4i (HP Laserjet III) LBP-8 III	Epson MX 80-II MX 80-IIa MX 80-III MX 100-III (Epson MX 80-III) FX 80 FX 100 (Epson FX 80) FX 100+ (Epson FX 80) FX 80+ (Epson FX 80) FX 185 (Epson FX 85) FX 286 (Epson FX 85) FX 286e (Epson EX 800, not colour) FX 85 FX 850 (Epson FX 85) FX 870 (Epson LX 100) FX 1000 (Epson FX 85) FX 800 (Epson FX 85) FX 1050 (Epson FX 85) FX 1170 (Epson LX 100) FX 2170 (Epson LX 100) GX 80 (Epson FX 80) EX 1000 (Epson EX 800) EX 800 LX 86 LX 100 LX 300 LX 400 (Epson LX 100) LX 850 (Epson LX 100) LX 1050 (Epson LX 100) JX 80 LQ 100 (Epson LQ 860) LQ 150 (Epson LQ 860) LQ 200 (Epson LQ 860) LQ 300 (Epson LQ860) LQ 400 (Epson LQ 860) LQ 450 (Epson LQ 860) LQ 500 (Epson LQ 860 up to 360x180 DPI) LQ 510 (Epson LQ 860) LQ 550 (Epson LQ 860) LQ 570 (Epson LQ 860) LQ 570+ (Epson LQ 860) LQ 800 (Epson LQ 860) LQ 850 (Epson LQ 860) LQ 850+ (Epson LQ 860) LQ 860 LQ 870 (Epson LQ 860) LQ 1000 (Epson LQ 860) LQ 1010 (Epson LQ 860) LQ 1050 (Epson LQ 860) LQ 1050+ (Epson LQ 860) LQ 1060 (Epson LQ 860) LQ 1070 (Epson LQ 860) LQ 1170 (Epson LQ 860) LQ 1500 (Epson LQ 860) LQ 2500 (Epson LQ 860) LQ 2500+ (Epson LQ 860) LQ 2550 (Epson LQ 860) EPL 5000 (HP Laserjet IIP) EPL 5200 (HP Laserjet III) EPL 5500 (HP Laserjet 4) EPL 7500 (Generic PostScript)	Genicom 7150 (HP Laserjet III) 7170 (HP Laserjet III)
Citizen LSP-100 (Epson FX 85) MSP-10 (Epson FX 80) MSP-15 (Epson FX S0) MSP-20 (Epson FX S0) MSP25 (Epson FX 80) MSP-40 (Epson EX S00) MSP-45 (Epson EX S00) MSP-50 (Epson EX 800) MSP-55 (Epson EX S00) 120-D 120-D+ 180E (Epson FX S0) 124D (Epson LQ 860) HQP-40 (Epson LQ S60) HQP-45 (Epson LQ 860) Prodot 9 (Epson EX 800 Not Colour) Prodot 24 (Epson LQ 560) Swift 9 Swift 9X Swift 24 Swift 24E Swift 24X Swift 90 Swift 90C Swift 200 Swift 240C Swift 224 (Swift 241) ABC 24 pin Mono	Hewlett Packard Deskjet Deskjet + Deskjet 310 B/W (HP Deskjet +) Deskjet 320 Deskjet 340 Deskjet 400 (This printer can only be used with A30x0, A4000, A7000 and Risc PC) Deskjet 500 (HP Deskjet +) Deskjet 500C Deskjet 510 (HP Deskjet +) Deskjet 520 (HP Deskjet +, Not at 600 x 300DPI) Deskjet 540 (This printer can only be used with A30x0, A4000, A7000 and Risc PC) Deskjet 550C Deskjet 560C Deskjet 600/C (This printer can only be used with A30x0, A4000, A7000 and Rise PC) Deskjet 660C (This printer can only be used with A30x0, A4000, A7000 and Risc PC) Deskjet 850C (This printer can only be used with A30x0, A4000, A7000 and Risc PC) Deskjet 1200C (HP Deskjet 550C) Deskjet 16000 (This printer is not support by !Printers) Laserjet II Laserjet III Laserjet II-PS Laserjet IID-PS Laserjet IIID-PS Laserjet 4 Laserjet 4M (Laserjet 4) Laserjet 4M+ (Laserjet 4 or Generic PostScript) Laserjet 4Si (Laserjet 4) Laserjet 4Si/MX (Laserjet 4) Laserjet 4L (Laserjet 4) Laserjet 4ML (Laserjet 4)	

Laserjet 4P (Generic PostScript)
Laserjet 4V A3 (HP Laserjet 4)
Laserjet 4V A3PS (Generic PostScript)
Laserjet 5L (LasJet-5)
Laserjet 5P (LasJet-5)
Laserjet 4MP (LasJet-5)
Laserjet 5M (LasJet-5)
Laserjet 5MP (LasJet-5)
Laserjet 5Si (lasJet-5)
PaintJet

IBM
4019/17
4019/39
4216
Pro-Printer X24E

Integrex
Colour Jet 132
Colour Jet 2000
Series II
Colourjet 600
Colourjet Master (HP Deskjet 500C)

Kodak
Ektaplus 7016 (HP Laserjet III)
Diconix 150+ (Epson FX 85)

Lexmark
ExecJet IIC 4076 (HP Deskjet 500C)
4039- 10R (PoScript)
Optra C (PoScript2)

Linotype
100
200

Mannesman Tally
MT-81 (Epson FX 85)
MT-85 (Epson FX 80)
MT-86 (Epson FX 80)
MT-87 (Epson FX 80)
MT-88 (Epson FX 80)
MT-130 (Epson EX 800)
MT-131 (Epson EX 800)
MT-150 (Epson EX 800)
MT-151 (Epson EX 800)
MT-230 (Epson FX 85)
MT-290 (Epson FX 80)
MT-340 (Epson FX 80)
MT-460 (Epson FX 80)
MT-490 (Epson FX 80)
MT-82 (Epson LQ 860)
MT-83
MT-84
MT-98 (IBM Proprinter X24E)
MT-99 (IBM Proprinter X24E)
MT-130/24 (Epson LQ 860)
MT-131/24 (Epson LQ 860)
MT-150/24 (Epson LQ 860)
MT-151/24 (Epson LQ 860)
MT-222 (Epson LQ 860)
MT-230 (Epson LQ 860)
MT-330 (Epson LQ 860)
MT-350 (Epson LQ 860)
MT-360 (Epson LQ 860)
MT-730 (HP Laserjet II)
MT-735 (HP Laserjet II)
MT-904 (HP Laserjet II)
MT-904PS (Generic PostScript)
MT-905 (HP Laserjet II)
MT-906 (HP Laserjet II)
MT-908 (HP Laserjet III)
MT-908PS (Generic PostScript)
MT-910 (HP Laserjet II)
MT-910DP (Generic PostScript)
MT-911 (HP Laserjet II)
MT-911PS (Generic PostScript)
MT T-WIN Laser (HP Laserjet II)
T7018 (HP Deskjet +)
T7040 (HP Deskjet 5000)
MobileWriter PS (Generic PostScript)

Minolta
SP 1000 (HP Laserjet III)
SP 1500 (HP Laserjet III)
SP 3000 (HP Laserjet III)
SP 3500 (HP Laserjet III)

Mitsubishi
6230 PS (Generic PostScript)
G210 PS (Generic PostScript)
G370S (Generic PostScript)
G6710PS (Generic PostScript)

NEC
P6 Plus
P60 (Epson LQ860)
P70 (Epson LQ860)
P2Q (Epson LQ 860)
P32Q (Epson LQ 860)
P62 (Epson LQ 860)
P72 (Epson LQ 860)
S102P (Generic PostScript)

OKI
OL400 ex (HP Laserjet II)
OL410 ex (HP Laserjet IV)
OL600 ex (HP Laserjet 11)
OL610 ex (HP Laserjet 4)

Olivetti
DM 124 (Epson LQ860)
JP 150
JP 150W(S) (Acorn JP150)
JP 250W(S) (HP Deskjet+)
JP 350 (HP Deskjet+)
JP 360
JP 360
JP 450 (HP Deskjet +)
JP 450C (HP Deskjet 500C)

Olympia
LP40 (Generic PostScript)

Panasonic
KX-P1080 (Epson MX 80-III)
KX-P1081 (Epson MX 80-III)
KX-P1082 (Epson MX 80-III)
KX-P1083 (Epson FX 80)
KX-P1091 (Epson MX 804-III)
KX-P1092 (Epson MX 80-III)
KX-P1150 (Epson LX 100)
KX-P1170 (Epson EX 800)
KX-P1180 (Epson EX 800)
KX-P1592 (Epson FX 80)
KX-P1595 (Epson FX 80)
KX-P1695 (Epson EX 800)
KX-P1123 (Epson LQ 860)
KX-P1124 (Epson LQ 860)
KX-P1124i (Epson LQ 860)
KX-P1540 (Epson LQ 860)
KX-P1624 (Epson LQ 860)
KX-P1654 (Epson LQ 860)
KX-P2023 (Epson LQ 860)
KX-P2180 (Epson EX 800)
KX-P2123 (Epson LQ 860)
KX-P2124 (Epson LQ 860)
KX-P2624 (Epson LQ 860)
KX-P3626 (Epson LQ 860)
KX-P4400 (HP Laserjet II)
KX-P4401 (HP Laserjet III)
KX-P4410 (HP Laserjet II)
KX-P4420 (HP Laserjet III)
KX-P4430 (HP Laserjet III)
KX-P4440 (HP Laserjet III)
KX-P4450i (HP Laserjet III)
KX-P4455PS (Generic PostScript)
KX-P5400 (HP Laserjet III)

QMS
CS 100
PS 1060 (Generic PostScriptFP)
PS 1660 (Generic PostScriptFP)
Magicolor (PoScript2)

Ricoh
Script Ten
Crystal Print Publisher II

Ricoh
6000
LP 1200 (HP Laserjet IV)

Sakata
5500 (Epson FX 85)

Samsung
SL1051A (HP Laserjet II)
SP0912 (Epson FX 85)

Seikosha
MP-1350 (Epson FX 85)
SP-200 (Epson FX 85)
SL-92 (Epson LQ 860)
SL-95 (Epson LQ 860)
SL-96 Colour (Epson LQ860)
SP-1900 Plus (Epson FX 85)
OP 115 (HP Laserjet 11)
Speedjet 200 (HP Laserjet III)
Speedjet 330 (HP Laserjet III)
Speedjet 360 (HP Deskjet+)

Sharp Electronics
JX 9460 (HP Laserjet III)
JX 9460PS (Generic PostScript)
JX 9660 (HP Laserjet III)

Star
Gemini 10
DP-510
FR-10 (Epson EX 800)
FR-15 (Epson EX 800)
LC-10 (Epson EX 800)
LC-15 (Epson EX 800)
LC-20 (Epson EX 800)
LC-90 (Epson EX 800)
LC-100 (Epson EX 800)
LC-200
ND-10 (Epson LX 80)
ND-15 (Epson LX 80)
NL- 10 (Epson LX 80)
NR-10 (Epson LX 80)
NR-15 (Epson LX 80)
ZA-200 (Epson LC 200)
ZA-250 (Epson LC 200)
LC 24-10 (Epson LQ 860)
LC 24-15 (Epson LQ 860)
XB 24-10 (Epson LQ 860)
XB 24-15 (Epson LQ 860)
LC 24-10 (Epson LQ 860)
LC 24-15 (Epson LQ 860)
LC 24-15 II (Epson LQ 860)
LC 24-20 (Epson LC 24-200)
LC 24-20 II (Epson LC 24-200)
LC 24-30 (Epson LC 24-200)
LC 24-100 (Epson LC 24-200)
LC 24-200 II (Epson LQ 860)
LC 24-200
LC 24-300 (Epson LC 24-200)
NB 24-10 (Epson LQ 860)
NB 24-15 (Epson LQ 860)
NB 15 (Epson LQ 860)
XB 24-200 (Epson LC 24-200)
XB 24-250 (Epson LC 24-200)
SJ-48 (Canon BJC 800) SJ-144
LaserPrinter 4 (HP Laserjet II)
LaserPrinter 4 II (HP Laserjet II)
LaserPrinter 4111 (HP Laserjet III)
LaserPrinter8 (HP Laserjet II)
LaserPrinter 8III (HP Laserjet III)
LS-5 (HP Laserjet II)
LS-5 EX (HP Laserjet III)
LS-5 Tr (HP Laserjet III)

Tandy
JP 250 (Acorn JP150)

Tektronix
Phaser 540 Colour Laser (Generic PostScript)
Phaser 220i Colour. Ther. Wax (Generic PostScript)

Texas Instruments
OmniLaser

Triumph Adler
JPR 7825 (HP Deskjet +)
SDR 7706S (HP Laserjet III)

Unisys
AP9312 Plus (HP Laserjet IV)
AP9316 (HP Laserjet III)
UMS Series Simplex (HP Laserjet III)