

PODULE RELEASE NOTE

for use with Podules

ARTHUR VERSIONS

To find out which version of Arthur you have, do the following:

- 1 If you are in the desktop, quit, by clicking on the **EXIT** icon and confirming.
- 2 Type *FX 0.
- 3 Press: .

VERSION 0.2


We recommend that you do not install your Podule until you have replaced your version of Arthur with version 1.2. See the letter about upgrades enclosed with your Archimedes.

VERSION 0.3

The Podule manager program is not present in this version of the system ROM. Until your system is upgraded to Arthur 1.2, you can use your Podule by loading the Podule manager program from the Welcome Disc. After installing the podule, take the following steps:

- 1 Switch on.
- 2 If you are in the desktop, quit, by clicking on the **EXIT** icon and
- 3 Put the Welcome Disc in drive 0.
- 4 Type:
*DIR :0
*LIB Library
*MODULES.PODULE

- 5 Initialise the Podule manager program by running the PodZap program from the Welcome Disc. To do this, type:

*PodZAP 

- 6 Type:

*PODULES

A message which informs you that the Podule is installed should appear on the screen.

It is necessary to repeat steps 1 to 5 before using Podules every time the system is reset.

VERSION 1.2

The Podule manager program is present in the system ROM. You do not need to load it from the Welcome Disc.