

Monitors known to work with ColourCard

CCSyncs Sync

Acorn Multisync 4 ... auto or 0

Taxan 770, 4 ... auto or 0

Toxon 770+ 4. . . auto or 0

Taxan 775 4 ... auto or 0

Taxan 795 4 ... auto or ()

Toxon 1095 4 ... auto or 0

NEC 3D. 7. . . auto or 0

Eizo T240i-M 4 ... auto or 0

Eizo F340i-W 4 t

Eizo F550i-M 4 1 t

Eizo F550i-W 4 ... auto or 0

Eizo T560i-T 4 ... auto or 0

Eizo F560i-W 4 . . . auto or 0

Eizo T660i-T 4 ... auto or 0

Eizo F760i-W 4 . . . auto or 0

Eizo F5500 5 ... auto or 0

Eizo 9060 7. . . auto or 0

CTX 17" 7. . . auto or 0

Notford 17' (no model number) 7 ... auto or 0

t These monitors require a special adaptor - contact Wild Vision for details.

Setting CCSyncs is described on page 29 of the manual. Setting Sync is described in the RISC OS User Guide.