



- NOTE:-
- 1] ~~SHUNTS ITEM~~ FITTED TO LINKS IN POSITIONS SHOWN THUS ☒
 - 2] ALL CONNECTORS [SK, PL, LK, IC SOCKETS] TO BE MOUNTED FLUSH AND PERPENDICULAR TO THE P.C.B.
 - 3] UNLESS OTHERWISE SHOWN, ALL ~~RADIAL~~ LEADED COMPONENTS TO BE MOUNTED PERPENDICULAR TO THE P.C.B. TO WITHIN +/-15 °.
 - 4] ENSURE REAR PANEL ITEM IS AT 90° TO THE P.C.B. AFTER ASSEMBLY.
 - 5] USE WIRE ITEM XX TO HOLD DOWN CRYSTALS
~~DO NOT SOLDER WIRE TO CAN.~~